




Field Service Spares Replacement Procedure – End Stops, Cam Plate & Base Harness, XX04 & 6003A/6004

Approval:

Approving Authority	Signature	Date
Doc Control:	Ron Chaffee / Signature on file. 	11-2-11
Assistant Service Manager, Global	John VanderJagt / Signature on file. 	11-2
Author:	Stuart Broadfield / Signature on file. 	11-02-11

Revision History

Rev.	ECO	Description of Change	Date
A	8841	Initial release	08-12-2011
B	9063	Clerical revisions	10-19-2011

Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

1. Brief Summary:

Troubleshooting document for inspecting and replacing the end stops, base harness and/or cam plate on a 04 series or 6003A/6004 limited azimuth antenna.

2. Theory of Operation:

Sea Tel limited azimuth antennas use a cam plate and two end stops, one in the pedestals base assembly and one in the azimuth post, to limit the system's rotation. During initialization, the antenna will drive clockwise until it reaches the upper limit of its mechanical rotation; at this point the encoder's relative position will be calibrated.

If the pedestal has been powered down at sea, the azimuth belt has failed or the azimuth rate sensor or encoder have failed the system could make violent contact with its end stops damaging them. Should an end stop break the pedestal is then able to continually rotate twisting the harness and damaging it. Once this has happened its common for the 24VDC on the harness to short and damage the ADE modem.

3. Inspection:

If the end stop has been damaged in either the azimuth post or base plate, but the thread is intact, they can be removed using a short length a 5/32" Allen wrench, with the pedestal in place. Replacement end stops should be secured with Loctite 2760 and set so that the stops "pick-up" the cam plate, but do not drag on the opposite structure.

If the end stop has damaged its thread, the pedestal will need to be removed from the base to allow the hole to be drilled and tapped to fit a Helicoil (Sea Tel kit part number: 135377) to allow for a replacement end stop to be installed.

Another potential failure which can happen is when the cam plate warps and binds between the base plate and azimuth post. This will require the azimuth post to be removed from the base and a replacement cam plate to be installed.



Lower End Stop (Base Plate)



Upper End Stop (Azimuth Post)

Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

4. Procedure for Replacing the End Stops and Cam Plate:

4.1. Tools:

- 10mm Wrench/Spanner or Socket
- 7/16" Wrench/Spanner or Socket
- 2mm Flat Blade (Terminal) Screwdriver
- Snips/Cutters
- 3/4" Wrench/Spanner or Socket
- Cable Ties/Tie Wraps
- #1 Phillips Screwdriver
- Box Cutter/Stanley Knife
- Acetone
- Drill
- 10.2mm Drill Bit
- M12 Tap
- Loctite 242 and 2760

4.2. Procedure.

The following procedure is for removing the pedestal from the base plate to allow repair of the end stop threads, inspection and /or replacement of the cam plate and replacement of the interface harness assembly.

***CAUTION:** Power down the pedestal before following this procedure.

***Note:** The replacement harness assembly will come without the connector installed. Do not install the connector at this time as it needs the clearance to be fed through the center of the base spindle.



1. Remove the radome top for access to the system, bolt sizes will either be 7/16" or 10mm.









2. Remove the 9-pin D-Sub connector from the ADE Modem using a 2mm flat blade screw driver.






3. Remove the 4 coax connections from the bracket (it's advisable to note their orientation).









Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>4. Using a #1 Phillips screwdriver remove the screw and P-clip securing the harness into the radome base.</p>	
<p>5. Remove the clamp securing the harness to the base plate using a 10mm wrench (if applicable).</p>	
<p>6. Remove the cable tie securing the harness to the base plate.</p>	
<p>7. Undo the four 3/4" nuts securing the pedestal base plate into the radome base.</p>	
<p>8. Secure the system around the cross level beam for lifting, taking care to allow clearance for any belts or cables.</p>	
<p>9. Lift the pedestal from the radome to enable an easier working environment.</p>	





Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>10. Using a 3/32" Allen wrench remove the back shell from the 9-pin D-sub connector, retain the back shells and hardware for future use.</p> <p>*Note: if the harness has been badly damaged it can be cut to allow easy removal from the pedestal as a replacement will need to be installed.</p>	
<p>11. Feed the base spindle harness up through the center of the azimuth post.</p>	
<p>12. Remove the snap bushing.</p>	
<p>13. Coil and secure the base spindle harness using a cable tie, ensuring the snap busing is on the harness assembly. (If the harness has been damaged this can be removed at this point).</p>	
<p>14. Using a #1 Phillips screwdriver, remove the azimuth belt retaining plate (if applicable).</p>	







Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>15. Remove the azimuth belt.</p>	
<p>16. Two M6 bolts can be set into any of the spare holes in the azimuth sprocket to allow leverage.</p>	
<p>17. Using a heat gun, heat the center of the azimuth spindle to soften the Loctite retaining the azimuth sprocket.</p>	
<p>18. Using the leverage points from the previous step, locate a pry bar across the sprocket onto the azimuth post and rotate the pedestal counter clockwise to undo the azimuth sprocket.</p> <p>*Note: Apply more heat if required.</p>	
<p>19. Once loose, remove the sprocket by hand.</p> <p>*CAUTION: It may be hot!</p>	
<p>20. Prepare to lift the pedestal from the base plate. Secure the system around the cross level beam for lifting, taking care to allow clearance for any belts or cables.</p>	







Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>21. Heat the center of the azimuth spindle to loosen the spindle from the bearings.</p>	
<p>22. Whilst prying the system from the base, apply even force on both sides to prevent damage to the azimuth bearings.</p>	
<p>23. Raise the pedestal from the base and set aside safely.</p>	
<p>24. Inspect the cam plate for wear, it's possible it can warp if it's come into contact with the end stops and will need to be replaced. Save the nylon washers for future use.</p>	
<p>25. If the thread in the base plate or azimuth post is too damaged to reuse, a Helicoil will need to be fitted (Sea Tel kit part number: 135377). The original hole will need to be drilled out to 10.2mm and tapped with an M12 thread.</p> <p>*Note: Drill the 10.2mm hole to tap an M12 thread; do not drill a 12mm hole.</p>	
<p>26. Install the Helicoil using Loctite 2760 (which is provided with the replacement end stop kit: 134374) so it sits flush with the upper edge of the base plate, or flush with the lower edge of the azimuth post.</p> <p>27. Once the Loctite 2760 on the Helicoil has set, install the end stop into the Helicoil using Loctite 2760 and a 5/32" Allen wrench.</p>	







Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>28. Use a guide to make sure the top of the end stop and the cam plate are flush. The same principal applies for the end stop in the azimuth post.</p>	
<p>29. Install the lower nylon washer over the azimuth spindle.</p>	
<p>30. Then, install the cam plate followed by the upper nylon washer.</p>	
<p>31. Lower the pedestal over the azimuth assembly, taking care to keep it straight to avoid stressing the azimuth bearings.</p> <p>*Note: Make sure the end stops are either side of the cam plate before lowering the pedestal to avoid contact when fitting.</p>	
<p>32. Rotate the pedestal and verify the end stops are positioned correctly and that the system has 680 degrees of rotation for a 3004, 4004 or 5004 or 540 degrees of rotation for a 6003A or 6004 antenna.</p>	
<p>33. Using a box cutter or razor knife blade, clean any old Loctite from the azimuth spindle and then clean the area with acetone.</p>	




Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>34. Now clean any old Loctite from the azimuth sprocket.</p> <p>*Note: It's advisable to dry fit the azimuth sprocket onto the azimuth spindle to make sure it fits freely with no resistance before applying Loctite.</p>	
<p>35. Apply Loctite 2760 to the lower threads of the azimuth sprocket.</p>	
<p>36. Install the azimuth sprocket and tighten it down slowly, making sure the Loctite 2760 works its way through the threads, then tighten the sprocket.</p> <p>37. Rotate the pedestal verifying it doesn't bind; if it does, back the azimuth sprocket off slightly and re-check.</p>	
<p>38. Clean any excess Loctite from the center of the azimuth sprocket.</p>	
<p>39. Reinstall the azimuth belt.</p>	
<p>40. Reinstall the azimuth belt retainer applying Loctite 242 to the screws (if applicable).</p>	

Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>41. Install the 15 pin D-sub connector of the replacement harness to the connector on the azimuth post, tightening the screws with a 2mm flat blade screwdriver. Connect the 4 coax cables using a 7/16" wrench, ensuring the connectors are color matched.</p> <p>*Note: If replacing the harness on a 6003A/6004 antenna see document: 135552 provided as part of the replacement 6003A/6004 interface harness kit (part number: 135379).</p>							
<p>42. Locate the snap busing in the center of the azimuth spindle.</p> <p>43. Feed the harness through the center of the base spindle and out the front of the base (feeding the coax cables and 9-pin D-sub connector through separately).</p>							
<p>44. Rotate the pedestal so it's facing in the same direction as the harness exits from the base.</p> <p>45. Work the harness up and down in the base spindle to straighten it. Then secure it to the mounting point of the base with a cable tie. (This is the center of the pedestals range of motion, meaning the harness will wrap and un-wrap an equal amount).</p>							
<p>46. Secure the harness using the cable clamp, applying Loctite 2760 to the bolt and tighten with a 10mm wrench (if applicable).</p>							
<p>47. Insert the pins into the numbered connections of the 9 pin D-sub connector in the following order:</p> <table style="margin-left: 20px;"> <tr> <td>9 - BLUE</td> <td>2 - WHITE/BROWN</td> </tr> <tr> <td>5 - BROWN</td> <td>8 - VIOLET</td> </tr> <tr> <td>1 - BLACK</td> <td>3 - WHITE/VIOLET</td> </tr> </table> <p>*Note: For the 3004, 4004 and 5004 only.</p>	9 - BLUE	2 - WHITE/BROWN	5 - BROWN	8 - VIOLET	1 - BLACK	3 - WHITE/VIOLET	
9 - BLUE	2 - WHITE/BROWN						
5 - BROWN	8 - VIOLET						
1 - BLACK	3 - WHITE/VIOLET						
<p>48. Install the back shells to the 9-pin D-sub connector, using the fully threaded screws and nuts to join them.</p> <p>49. Install the split washers on the screws to attach the connector to the ADE modem.</p>							

Field Service Procedure – End Stops, Cam Plate & Base Spindle Harness, XX04 & 6003A/6004

<p>50. Secure the system around the cross level beam for lifting, taking care to allow clearance for any belts or cables.</p>	
<p>51. Lower the system into the radome base with the base harness facing towards the bow of the vessel, (which is typically with the harness exiting away from the hatch depending on the orientation the radome has been installed on the vessel).</p>	
<p>52. Install the system into the radome base using the 3/4" hardware removed earlier using Loctite 2760.</p>	
<p>53. Reattach the 9-Pin D-Sub connector to the ADE modem using a 2mm flat blade screwdriver.</p> <p>54. Reconnect the four coax cables in their original orientation using a 7/16" wrench.</p> <p>55. Install the P-clip on the harness and secure to the radome base using Loctite 242, secure the coax and harness cables together using cable ties.</p>	